

ROLLEX MEDICAL (AUST) PTY LTD  
 PO Box 170 | Mt Kuring-gai 2080 | Sydney, NSW | Australia  
 Phone: 1300 880 441 | Fax: 1330 880 451  
 Email: sales@rollexmedical.com | www.rollexmedical.com.au

## Model Variations

Eco 250 R/DT – Solid Door, hot gas defrost  
 Eco 250 R/GDT – Glass Door, hot gas defrost



MATOS PLUS Eco 250 R/GDT



## Specifications

Capacity	250L	Power	330W
Dimensions External	620w x 1260h x 650d	Air convection	Forced Air
Dimensions Internal	520w x 1060h x 420d	Temperature range	0°C – +10°C
Max shelf workload	10kg	Controller	Microprocessor with external LCD graphic display
Max unit workload	50kg	Interior	Aluminium (s/steel optional)
Door	Solid/Glass option	Housing	Powder coated sheet (s/steel optional)
Weight	61kg	Temperature resolution	0.1°C
Shelves fit/max	3/4	Temperature fluctuation at 4°C	+/- 0.5°C
Gas defrost	Optional	Voltage 50/60Hz	115/230V
Refrigerant	R134A	Internal light	Yes
Refrigerant amount	0.082kg	Door Open Alarm	Yes
Castors	Yes	Access Port	Yes

The Matos® Plus Eco fridge series is a new range of purpose built Medical and Vaccination Refrigerators utilising patented technology. The cabinet and componentry have been specially designed for use in the Medical field.

### Interior Finish

All Matos® Plus Eco fridges come with a high quality aluminium interior and use polyurethane foam thermal insulation. A stainless steel interior is also offered as an option.

### Lock Fitted as Standard

Maintains security and ensures the unit can only be opened by authorised personnel.

### Solid or Glass Door Options

Most models come with solid or glass door options enabling you to select the format which best suits your requirements.

### Auto Defrost

The advanced controller initializes a regular defrost sequence to decrease the chance of ice build-up while maintaining the temperature below 8°C. Matos® Plus Eco fridges can also be ordered with a gas defrost capability.

### Energy Efficient

Matos® Plus Eco fridges are more energy efficient and kinder to the environment, meaning the running costs of the refrigerator are kept as low as possible.

### 3 Year Extended Warranty

When serviced by an approved service technician, the warranty is extended to 3 years.

### CCTC / QCPP Certified

CCTC and QCPP Approved Vaccine Pharmacy Graded Refrigerator.