

ROLLEX MEDICAL (AUST) PTY LTD  
 PO Box 170 | Mt Kuring-gai 2080 | Sydney, NSW | Australia  
 Phone: 1300 880 441 | Fax: 1330 880 451  
 Email: sales@rollexmedical.com | www.rollexmedical.com.au

The Matos® Plus Eco fridge series is a new range of purpose built Medical and Vaccination Refrigerators utilising patented technology. The cabinet and componentry have been specially designed for use in the Medical field.

## Model Variations

- Eco 625 R/DT – Solid Door, hot gas defrost
- Eco 625 R/GDT – Glass Door, hot gas defrost



MATOS PLUS Eco 625 R/GDT

Endorsed by



## Specifications

Capacity	625L	Power	400W
Dimensions External	735w x 1990h x 860d	Air convection	Forced Air
Dimensions Internal	600w x 1510h x 690d	Temperature range	0°C – +10°C
Max shelf workload	30kg	Controller	Microprocessor with external LCD graphic display
Max unit workload	150kg	Interior	Aluminium (s/steel optional)
Door	Solid/Glass option	Housing	Powder coated sheet (s/steel optional)
Weight	115kg	Temperature resolution	0.1°C
Shelves fit/max	3/11	Temperature fluctuation at 4°C	+/- 0.5°C
Gas defrost	Optional	Voltage 50/60Hz	115/230V
Refrigerant	R290A	Internal light	Yes
Refrigerant amount	50 grams	Door Open Alarm	Yes
Castors	Yes	Access Port	Yes

## Interior Finish

All Matos® Plus Eco fridges come with a high quality aluminium interior and use polyurethane foam thermal insulation. A stainless steel interior is also offered as an option.

## Lock Fitted as Standard

Maintains security and ensures the unit can only be opened by authorised personnel.

## Solid or Glass Door Options

Most models come with solid or glass door options enabling you to select the format which best suits your requirements.

## Auto Defrost

The advanced controller initializes a regular defrost sequence to decrease the chance of ice build-up while maintaining the temperature below 8°C. Matos® Plus Eco fridges can also be ordered with a gas defrost capability.

## Energy Efficient

Matos® Plus Eco fridges are more energy efficient and kinder to the environment, meaning the running costs of the refrigerator are kept as low as possible.

## 3 Year Extended Warranty

When serviced by an approved service technician, the warranty is extended to 3 years.

## CCTC Certified

CCTC and QCCP Approved. Exclusively endorsed by The Pharmacy Guild of Australia.